

Residential LED Functions Sheet

To arm system GREEN READY LIGHT must be on!

If green light is not on, look at red LED numbers to find out what zone is open.

ARMING AWAY- green ready must be on – enter your four-digit code (1234) or press and hold away button for five seconds and wait for red-armed light and audible count down to come on.

STAY ARMING- green ready must be on – enter your four-digit code (1234) and stay in the house or hold the stay button for five seconds and wait for red-armed light to come on. **NOTE:** There is no audible count down when stay button is used.

DISARMING- enter your four-digit code (1234) - Turns off protection.

BYPASS - For example (* + 1 + the zone 06 + # + your code) this bypasses zone 6 and arms the system with a bypass - This temporarily removes a protected zone from the system. Once the system has been disarmed the bypass will be removed.

ACCIDENTAL ALARM - WHAT TO DO: Enter your four-digit code. This will turn the siren off and sends a cancellation signal to the monitoring station. After disarming system, please **call Huronia Alarm and Fire Security Inc.** and provide your ID Number.

If you make a mistake entering in your four digit-code press the # and begin again.

Our monitoring station phone numbers are;

705 527 9311 or 1 888 363 9311

